

Gyro Mixer Maintenance



For a colorful world!

SANTINT[™]

Time Type	Daily Maintenance	Monthly Maintenance	Semi-annual Maintenance	Annually Maintenance
Gyro mixer(G2 、 G4、 G4b、 G5、 G5b)	Keep the interior of the machine clean and wipe off paint on the side screws and the guide shafts with a piece of wet cloth	<ol style="list-style-type: none"> 1.Lubricate the screw and guide shafts every three month 2.Lubricate guide track every three month 3.Check the side paneling whether badly worn 	<ol style="list-style-type: none"> 1.Lubricate the cone-gear transmission system 、 initiative-clamping cone-gear and passive initiative-clamping cone-gear once every half year 2.Open the cover of the synchronous belt and check the synchronous belt whether badly worn 	Open the back cover to check belt tension every year

Content

Part One

Daily Maintenance 4

Part two

Monthly Maintenance 5

Part three

Semi-annual Maintenance 8

Part four

Annually Maintenance 10

Part One

Gyro Mixer Daily Maintenance



Keep the interior of the machine clean and wipe off paint on the side screws and the guide shafts with a piece of wet cloth

Part two


Monthly Maintenance



Lubricate the screw and guide shafts every three month




Lubricate guide track every three month




Check the side paneling whether badly worn

Part three

Semi-annual Maintenance



Lubricate the cone-gear transmission system 、 initiative-clamping cone-gear and passive initiative-clamping cone-gear once every half year



Open the cover of the synchronous belt , check the synchronous belt whether badly worn and tension every half year

Part four

Annually Maintenance



Open the back cover to check belt whether tension every year